




Common Radio Receiver Hook-up



Touchless Wall Switch

Connect to CN3

Typical Touchless Wall Switch

